

Manual

Dog Pulling System

Attaching the Tow Bar Components:

- There are three parts, assembled in two pairs.

Note! If you already have a pulk/hiking drag system for a person, you can use the same straight and flexible component.

Attachment Hook:

This is pre-attached to the harness upon delivery.

Assembly Steps:

1. Open and remove the Velcro locking pins from all aluminum tubes.
2. Insert the shorter tube into the base of the plastic frame.
3. Slide the longer, straight tube into the first opening and secure it with the locking pin.
4. Insert the flexible nylon puller, then attach the webbing hook and secure it firmly with the locking pin, as shown in the illustration.
5. Repeat these steps on the opposite side.



Connecting the Tow-Bar to the harness:

1. Place the strap over the puller and let it rest freely in the loop. Tighten securely.
2. Ensure that the puller can move freely back and forth.
3. Attach the hook to the harness.

